

# Add a lively new dimension to your Yamaha Disklavier

Disklavier Upgrade Unit

**DKC-900** 



### Enhances your listening pleasure

The DKC-900 lets your Disklavier do more than simply play back piano songs. It also lets it recreate performances by top artists—many recorded exclusively for Yamaha. Whether it's an ensemble, orchestra, or vocal performance, you'll be immersed in pure musicality.

### Connects to your smart device

The ENSPIRE Controller app (for iOS or Android) lets you connect your Disklavier with a smartphone or tablet. Using the app, it's easy to select and download songs or record your own performance.

### Seamless design

The DKC-900 unit is compact enough to be installed unobtrusively on a Disklavier. It will blend in seamlessly with the elegant lines of your Yamaha piano.





#### **DKC-900** compatible models

Category		Series	Model	Control Unit
Upright piano	Disklavier	E3 Series	E3	DKC-800
Grand piano	Disklavier	Mark IV Series	Mark IV, Mark IV Pro	DMC-100
	Disklavier	E3 Series	E3 Pro, E3	DKC-800

#### **Specifications**

POWER, VOLUME -/+, PLAY/PAUSE, MAINTENANCE		
AUTO PLAY, AUTO OFF MODE, WLAN		
224 x 130 x 76 mm		
MIDI IN, MIDI OUT		
OUTPUT, OMNI (SYNC) IN, OMNI (SYNC) OUT, DIGITAL OUT, HEADPHONE (mini)		
CFX Binaural Sampling, CFX Stereo Sampling		
414.8 Hz to 466.8 Hz (tunable in 0.2 Hz increments)		
256 notes (max.)		
16 voices (Piano, Electric Piano 1, Electric Piano 2, Electric Piano 3, Harpsichord 1, Harpsichord 2, Vibraphone, Celesta, Pipe Organ 1, Pipe Organ 2, Pipe Organ 3, Pipe Organ 4, Jazz Organ, Strings, Choir, Synth Pad)		
XG, GM		
AC 100 V to 240 V, 50/60 Hz		
12 W		
Owner's manual, Built-in song list, Audio cable, AC adaptor, USB wireless LAN adaptor, Bracket		
Bracket for CF Series Grand Piano (DKCB-900CF)		
·		

Specifications are subject to change without prior notice.

- The DKC-900 does not play floppy disks or CDs.
- Performances that you've recorded on your Disklavier may get erased when you install the DKC-900. Be sure to back up your data on a USB drive or other memory device.

#### Equipment to mount

#### Switch box



#### Control center unit



#### Installing on the piano

#### Grand piano



The control center unit is attached underneath the piano. The switch box is attached under the left side of the keyboard. Some wiring work is required.

#### Upright piano



The control center unit is attached to the rear of the piano. The switch box is attached under the right side of the keyboard. Some wiring work is required.

## Rest assured—installation of the upgrade unit is performed in your home by a piano technician or an authorised Piano Service Station

- This installation can be done in your home. It is not necessary to move your piano to a dealer's store
  or other location.
- 2. The installation process may take a few hours.
- 3. When installing in an upright piano, the instrument will need to be moved away from the wall.
- 4. After the installation, it is recommended that you have your piano tuned and regulated.

