





USB AUDIO INTERFACE URX44V URX44 URX22 v1.2 Block Diagram

Block Diagram (URX44V, URX44)




*1) INS FX are available for sampling frequencies below 96 kHz
*2) FX2 are available for sampling frequencies below 96 kHz

DAW Integration Block Diagram (URX44V, URX44)




*1) INS FX are available for sampling frequencies below 96 kHz
 *2) FX2 are available for sampling frequencies below 96 kHz

Block Diagram (URX22)



*1) INS FX are available for sampling frequencies below 96 kHz
 *2) FX2 are available for sampling frequencies below 96 kHz

DAW Integration Block Diagram (URX22)



*1) INS FX are available for sampling frequencies below 96 kHz
 *2) FX2 are available for sampling frequencies below 96 kHz